

• Trouble shooting

Q. All I got on the screen is black.

- A. Check second LED lamp of the interface is on, if not, check A/V sources connected are working well.
(Second lamp indicates AV sources connected works well.)
Check interface connection has been done well.

Q. Set mode not appear

- A. Check DIP Switch.

Q. OEM image is not displayed.

- A. Check interface's LCD In/Out cable connection. If the status keeps on, inform to manufacturer.

Q. Screen displays only white color.

- A. Check LCD out cable is connected well, if this status keeps, inform to manufacturer.

Q. After connecting CAN wires, the screen shows no image while the gear is shifted into "P"

- A. Check whether plug&play cables are properly connected.

CarNavITech